O ICOM

USB DRIVER

You can set up an Icom radio by connecting it to a PC through a USB cable.

Read this installation guide and install the USB driver to your PC, before connecting the USB cable.

The descriptions in this guide are based on the following conditions:

- You have already downloaded the latest USB driver from the Icom Download Service website. https://www.icomjapan.com/support/
- The operating system of the PC is Windows 10.
 The installation steps or displayed dialog may differ, depending on the operating system.

TABLE OF CONTENTS

1. OVERVIEW	1
System requirements	
2. PRECAUTIONS	2
Before the installation	2
Before connecting to a PC	2
After the installation	
Important	2
About compatible radios	

4. FOR YOUR REFERENCE......5

4-1 COM Port setting54-2 Uninstalling the driver64-3 Audio considerations6

1. OVERVIEW

System requirements

The following hardware and software are required:


PC

- Microsoft Windows 11 (64 bit)
- Microsoft Windows 10 (32/64 bit)
- Microsoft Windows 8.1 (32/64 bit)* *Except for the "RT" version.
- A USB 1.1, 2.0, or 3.0 port

NOTE:

• If you want to use the Icom radio on a Windows 11 PC, please install the driver for Windows 10.

Cable • A USB cable



NOTE:

 Purchase the proper USB cable according to your PC's USB port.
 For the Type-A port: User supplied

For the Type-C port: OPC-2418 (optional)

- Use a USB cable for data communication. You cannot set up the radio with a cable that is made for charging only.
- Depending on the length of a third-party USB cable, the radio may not work correctly, even if the PC recognizes it. Use a cable that is as short as possible.

All other products or brands are registered trademarks or trademarks of their respective holders.

2. PRECAUTIONS

Before the installation

- When installing the driver, confirm Windows has completed its startup, and then log in as the administrator.
- Confirm no other application is running.

Before connecting to a PC

- The USB driver does not support the automatic recognition system. **NEVER** connect the USB cable between the radio and the PC until AFTER the USB driver has been installed. See "Installing the driver" on page 3 for details. Once the driver has been installed, a PC software can be used by just connecting the USB cable.
- Directly connect the radio and the PC. Icom is not responsible for improper operation when connecting them through a USB hub.

After the installation

- Uninstalling the USB driver You cannot uninstall the USB driver for individual device. After uninstalling the USB driver, none of the devices that require this driver can be recognized by the PC.
- When another radio is connected A COM port number is automatically added after turning ON the device.

Important

- Depending on your PC performance (OS, environment, and so on), the USB audio may be interrupted, or a control by the PC software may get delayed.
- If the CPU has a heavy load, the USB audio is easily interrupted.
- The settings of the installed audio player may be changed after connecting the radio to the PC.

About compatible radios

• The radios that require this driver are shown on the lcom website.

https://www.icomjapan.com/support/

3. INSTALLING THE DRIVER

NOTE:


- **NEVER** connect the USB cable between the radio and the PC until the USB driver has been installed. Disconnect the cable, if connected, before starting the USB driver installation.
- This USB driver does not support the automatic recognition system.
- ① The displayed dialog, indications, or operations may differ slightly from the following instructions, depending on your system version and settings.
- Log on the PC as the administrator. Confirm that the radio and PC are not connected, and no other application is running.
- 2. Extract the downloaded USB driver, and then open the folder that contains the installer.
- 3. Double-click the following file:
 - For the 32 bit version OS: setup32.exe
 - For the 64 bit version OS: setup64.exe
- 4. When the "User Account Control" dialog is displayed, click <Yes>.
- 5. When the language select window is displayed, click <OK>.



6. When the install screen is displayed, click <Next>.



7. When the "Ready to Install the Program" dialog is displayed, click <Install>.



Windows starts installing the driver.8. After the installation has completed, click

<finish>. Icom USB Serial Port Driver - Ir</finish>	stallShield Wizard
	InstallShield Wizard Complete
	The InstallShield Wizard has successfully installed Icom USB Serial Port Driver. Click Finish to exit the wizard.
	Click


(res Continued on the next page)

Finish

3. INSTALLING THE DRIVER

 Connect the USB cable between the radio and the PC, as shown below. Then, turn ON the radio's power.

Confirm the USB cable connector shape.



To a USB port

To a [microUSB] port


10. The installation icon is displayed on the taskbar as shown below, and then Windows starts installing the driver.




- After the driver installation has completed, the installation icon disappears.
- Depending on your system version or setting, you may be prompted to restart the PC. In this case, follow the instructions on the screen.

After the driver installation has completed, confirm the port connection and port number.

11. Right-click Windows icon, and then click [Device Manager].



12. Double-click "Ports (COM & LPT)" on the "Device Manager" screen.



- When the driver is completely installed, "IC-705 Serial Port A (CI-V) (COM★)" is displayed. The screen is an example of the USB serial COM port number "5."
- The COM port number may differ, depending on the PC environment.
- If "!" or "×" is displayed on the "Device Manager" screen, the driver may not correctly be installed. In such a case, uninstall the USB driver, and then reinstall it.

4. FOR YOUR REFERENCE

After the PC and radio are connected, you can remotely control the radio using the CI-V commands. The radio has a conversion function between USB and Serial.

4-1 COM Port setting

To change the COM Port number setting after you have installed the USB driver, connect the radio to the PC first, and then turn ON the device.

1. Right-click Windows icon, and then click [Device Manager].


_	System	
	Device Manager 🛛 Olick	
	Network Connections	
	Disk Management	
	Computer Management	
	Windows PowerShell	
	Windows PowerShell (Admin)	
	Task Manager	
	Settings	
	File Explorer	
	Search	
	Run	
	Shut down or sign out	>
	Desktop	
	❶ Right-click ⊟i 📑	(

2. Right-click "IC-705 Serial Port A (CI-V) (COM*)," and then click "Properties."

The COM port number is displayed instead of "*." If the radio has two COM ports, two COM port numbers are displayed.

> 🖵 Network adapters	
[™] [₽] 0 Right-click	COM1)
IC-705 Serial Port A (CI-V	
> 🛱 Print queues	Disable
> D Processors	Uninstall
> Software devices	
> 🐐 Sound, video and game cc	2 Click ardware changes
> 🍇 Storage controllers	Properties
> 🏣 System devices 🛛 🔤	. Eoperado
> 🏺 Universal Serial Bus controlle	:rs

 Click the [Port Settings] tab, and then click <Advanced...>.



4. Select the COM port number, and then click <OK>.

Advanced Settings for COM5	×
☑ <u>U</u> se FIFO buffers (requires 16550 compatible UART) Select lower settings to correct connection problems.	2 Click
Select higher settings for faster performance.	Cancel
Receive Buffer: Low (1)	High (14) (14)
ransmit Buffer: Low (1)	High (16) (16)
COM Port Number	

5. Click <OK> to close the screen.

IC-705 Se	rial Port A (Cl-	V) (CON	16) Prope	erties			×
General	Port Settings	Driver	Details	Events	Power Mana	gement	
			er second <u>D</u> ata bits <u>P</u> arity <u>S</u> top bits w control	8 None		> > >	
			A	Ivanced.	<u>Restor</u>	re Defaults	
					ОК	Cancel	

After changing the COM port number, you may not be able to immediately use the selected COM port number.

In this case, disconnect the USB cable once, and then reconnect the cable.

4. FOR YOUR REFERENCE

4-2 Uninstalling the driver

The displayed dialogs or indications may differ slightly from the following instructions, depending on your system version and settings.

1. Click the Windows icon on the taskbar, then click the [Setting] icon.



2. Click [Apps].



3. Click "Icom USB Serial Port Driver."

← Settings	
û Home	Apps & features
Find a setting P	Choose where to get apps
Apps	Installing apps only from Windows Store helps protect your device.
IE Apps & features	Anywhere V
E Default apps	Apps & features
印_ Offline maps	Optional features
Apps for websites	App execution aliases
□ Video playback	Search, sort, and filter by drive. If you would like to uninstall or move an app, select it from the list.
	٩
	Sort by: Name $ \lor $ Filter by: All drives $ \lor $
	Icom USB Serial Port Driver 56.0 5/14/2C Click

- 4. Click <Uninstall>.
 - When the "User Account Control" dialog is displayed, click <Continue>.

pps installing approprint from Windows Store helps protect your device. Apps & leatures Apps & leatures Apps & features Officient apps Apps & features Optional features Apps for websites App execution allows App
Apps Installing apps only from Windows Store helps protect your device. E Apps & features B Apps & features IQ Optional result Days for websites Apps execution allases Security of the by protectly our device. Apps & features
Anywhere Anywhere E Apps & features Apps & features To Office maps Optional features B Apps for websites Sape receivion allases Sacent, sort, and there by drive. If you would like to uninstall or
Default apps Apps & features at Othine maps Optional features at post for websites Apps execution allates asps for websites Search, sort, and filter by drive. If you would like to uninstall or
Giffine maps Optional features App execution alloares Search, sort, and filter by drive. If you would like to uninstall or
Apps for websites Apps for websites Search, sort, and filter by drive. If you would like to uninstall or
Apps for websites Search, sort, and filter by drive. If you would like to uninstall or
inde an app, seech normale the
P Startup
Sort by: Name \checkmark Filter by: All drives $$
Icom USB Serial Port Driver 56.0 KB 5/14/2020
Modify Uninstall

5. Follow the instructions on the screen to uninstall.

4-3 Audio considerations

- For modulation input from the PC, the radio's USB port must be set as the modulation input source connector. You can set the modulation input source connector in the radio's Set mode, or using CI-V system commands. See the instruction manual of your radio for details.
- If you want to monitor the received audio through the PC's speaker or use the audio from the PC's microphone as the modulation input, see the instruction manual of your audio software.